


# Instruction Manual

## EBARA Submersible Semi-vortex Sewage Pumps

### MODEL DVS

Distributor: PUMPX  
www.pumpx.com  
www.pumpx.vn



## Introduction

Check the following points upon receipt of your pump:

- (1) Is the pump exactly what you ordered? Check the nameplate. It is especially important that you check whether the pump is to be used with 50 Hz or 60 Hz.
- (2) Has any damage occurred during shipment? Are any bolts or nuts loose?

- (3) Have all necessary accessories been supplied? (For a list of standard accessories See **Construction.**)

We recommend that you keep a spare pump on hand in case of emergencies. Keep this instruction manual in a safe place for future reference.

## Specifications

Check the nameplate for your pump's head (HEAD), discharge volume (QUANT.), speed (SPEED), motor voltage and current. Other specifications are listed in the chart below.

Standard specifications		
Liquid handled	Type	River, rain and spring water, sewage
	Temperature	DVS, DVSA ..... 0 ~ 40°C DVSJ ..... 0 ~ 32°C
	Max. size of foreign matter	Less than 60 ~ 70% of diameter
Materials		Impeller....cast iron
Motor type		Dry type submersible motor
Shaft seal lubrication oil		Turbine oil No. 32 (ISO VG32)
Maximum water depth		0.15 ~ 1.5kW.....4m, 2.2 ~ 3.7kW.....8m
Installation		Floor model

Note: Be careful not to exceed the given specifications in the use of your pump.

# Installation

## 1. Check the following before beginning installation.

Insulation resistance measurement:


For three phase motor:

With the motor and cable (excluding the power supply connections) immersed in water, use a megger to measure the insulation resistance between the ground wire and each phase of the motor, and again between each phase of the motor.

For single phase motor:

Use a megger to measure the insulation resistance between both prongs of the plug and grounding wire.

The megger should indicate an insulation resistance of not less than 20mega ohms. While making the measurement, keep the power supply cable off the ground.



## 2. Installation

(1) Under no circumstances should the cable be pulled while the pump is being transported or installed. Attach a chain or rope to the grip and install the pump.

(2) This pump must not be installed on its side or operated in a dry condition. Ensure that it is installed upright on a secure base.

(3) Install the pump at a location in the tank where there is the least turbulence.

(4) If there is a flow of liquid inside the tank, support the piping where appropriate.

(5) Install piping so that air will not be entrapped. If piping must be installed in such a way that air pockets are unavoidable, install an air release valve wherever such air pockets are most likely to develop.


(6) Do not permit end of discharge piping to be submerged, as backflow will result when the pump is shut down.

(7) Non-automatic pumps (model DVS) do not have an automatic operating system based on built-in floats. Always keep an eye on pump operating water level. Do not operate the pump for a long time with the water level near the minimum operating level as the automatic cut-off switch incorporated inside the motor will be activated. To avoid dry operation, install an automatic operating system, as shown in Fig. 2 and maintain a safe operating water level.



(8) For automatic pumps (DVSA), install the floats as shown in Fig. 3. The pump may not start if a float switch touches the wall of the water tank or the piping. Install the floats so that this will not happen.

(9) Models DVSA and DVSA will undergo automatic alternate operation when they are paired. Position the floats for these automatic alternate operation pumps as shown in Fig. 4. The pumps may not operate correctly if the floats are in the wrong location.

Refer to the quick discharge connector instruction manual for details on the installation of pumps so equipped.




Floats can be set to the desired water level by changing their location on the float support.



### 3. Electrical wiring

- (1) Wiring
  - a) Wire as indicated for the appropriate start system as shown in Fig. 5.
  - b) Loose connections will stop the pump. Make sure all electrical connections are secure.
- (2) Cable
  - a) Never let the end of the cable contact water.
  - b) If the cable is extended, do not immerse the splice in water.
  - c) Fasten the cable to the discharge piping with tape or vinyl strips.
  - d) Install the cable so that it will not overheat. Overheating is caused by coiling the cable and exposing it to direct sunlight.
- (3) Grounding

Please ground motor for safety.
- (4) Use short circuit breakers to prevent danger of electrical shock.



# Operation

## 1. Before starting the pump

- (1) After completing installation, measure the insulation resistance again as described in **Installation**.
- (2) Check water level.  
If the pump is operated continuously for an extended period of time in a dry condition or at the lowest water level, the motor protector (less than 7.5kW) or the thermal detector (more than 11kW) will be activated. Constant repetition of this action will shorten pump service life. Do not start the pump again in such a situation until after the motor has completely cooled.




Fig. 7

## 2. Test operation....

### Non-automatic pump (DVS)

### Automatic pump (DVSA)

- (1) Turn the operating switch on and off a couple of times to check for normal pump start.  
For the DVSA pump, the upper float switch must be raised for the pump to start.
- (2) Next, check direction of rotation. If discharge volume is low or unusual sounds are heard when the pump is operating, rotation has been reversed. When this happens, reverse two of the three wires (see Fig. 7).




Fig. 8

## 3. Test operation....

### Automatic alternate pumps (DVSJ)

Check automatic alternate operation of pump No. 1 (DVSJ) and pump No. 2 (DVSA) as follows (see Fig. 8).

- (1) When the water level reaches pump No. 1 start level, pump No. 1 will start and water will be pumped until pump No. 1 stop water level is reached.  
At this point the automatic alternate operation circuit built into pump No. 1 will stop the pump.  
The water level will now be at pump No. 2 start level. Pump No. 2 will start and pump water until its stop water level is reached. The process is repeated when the water level is again at pump No. 1 start level.
- (2) If the water flowing into the water tank exceeds the amount being pumped by pump No. 2 (abnormal water increase) and the water level rises to pump No. 1 abnormal start water level, pump No. 1 will start to operate. The two pumps will then be operating simultaneously in parallel operation.

# Maintenance

Check pressure, output, voltage, current and other specifications. Unusual readings may indicate trouble. Refer to **Troubleshooting** and correct as soon as possible.

## 1. Daily inspections

- (1) Check current and ammeter fluctuation daily. If ammeter fluctuation is great, even though within the limits of pump rating, foreign matter may be clogging the pump.  
If the quantity of liquid discharged falls suddenly, foreign matter may be blocking the suction inlet.

## 2. Regular inspections

- (1) Monthly inspections  
Measure the insulation resistance. The value should be more than 1M ohm. If resistance starts to fall rapidly even with an initial indication of over 1M ohm, this may be an indication of trouble and repair work is required.
- (2) Annual inspections  
The service life of the mechanical seal can be prolonged by replacing the oil in the mechanical seal chamber once a year. Water mixed with the oil or a cloudy texture are indications of a defective mechanical seal requiring replacement. When replacing the oil, lay the pump on its side with filler plug on top as shown in Fig. 9.

Inject turbine oil No. 32 (ISO VG-32) until it overflows.

- (3) Inspections at 3-5 year intervals  
Conduct an overhaul of the pump. These intervals will preclude the possibility of future trouble.

## 4. Parts that will need to be replaced

Replace the appropriate part when the following conditions are apparent.


Replaceable part	Mechanical seal	Oil filler plug gasket	Lubricating oil	O-ring
Replacement guide	Whenever oil in mechanical seal chamber is clouded	Whenever oil is replaced or inspected	Whenever clouded or dirty	Whenever pump is overhauled
Frequency	Annually	A half yearly	A half yearly	Annually

Above replacement schedule is based on normal operating conditions.

Part \ Motor output	0.15kW	0.25kW	0.4kW	0.75kW	1.5kW	2.2kW	3.7kW
Mechanical seal	13φ		15φ		20φ	30φ	
Oil filler plug gasket	Inner diameter × outer diameter × thickness = 10φ × 18φ × 0.8t or 13φ × 23φ × 0.8t						
Lubricating oil (turbine oil No. 32)	120cc		180cc		650cc	1180cc	
O-ring	G80		G95		G105	3φ × 170	

## 3. Precautions when operation is suspended

- (1) If operation is to be suspended for a prolonged period of time with the pump immersed in water, measure the insulation resistance of the motor occasionally. If resistance is normal, operate pump to prevent rust from developing on moving parts. Follow the instructions under **Operation** when pump operation is to be resumed.
- (2) For dry storage, clean out pump and store in a dry place. Follow the instructions under **Installation** and **Operation** when pump operation is to be resumed.



Note: For cold weather storage, turn the unit on its side, discharge elbow in the down position. This is to make sure all water has drained from the volute. Then store the unit in a dry place.


# Troubleshooting

Trouble	Cause	Remedy
Does not start. Starts, but immediately stops.	(1) Power failure (2) Large discrepancy between power source and voltage (3) Significant drop in voltage (4) Motor phase malfunction (5) Electric circuit connection faulty (6) Faulty connection of control circuit (7) Fuse blown (8) Faulty magnetic switch (9) Water is not at level indicated by Float (10) Float is not in appropriate level (11) Float defective (12) Short circuit breaker is functioning (13) Foreign matter clogging pump (14) Motor burned out (15) Motor bearing broken	(1) ~ (3) Contact electric power company and devise counter-measures  (4) Inspect connections and magnetic switch (5) Inspect electric circuit (6) Correct wiring (7) Replace with correct type of fuse (8) Replace with correct type of magnetic (9) Raise water level (10) Move float to an appropriate starting level (11) Repair or replace (12) Repair location of short circuit (13) Remove foreign matter (14) Repair or replace (15) Repair or replace
Operates, but stops after a while.	(1) Prolonged dry operation has activated motor protector and caused pump to stop (2) High liquid temperature has activated motor protector and caused pump to stop	(1) Raise stop water level (2) Lower liquid temperature
Does not pump. Inadequate volume.	(1) Reverse rotation (2) Significant drop in voltage (3) Operating a 60Hz pump on 50Hz (4) Discharge head is high (5) Large piping loss (6) Low operating waterlevel causes air suction (7) Leaking from discharge piping (8) Clogging of discharge piping (9) Foreign matter in suction inlet (10) Foreign matter clogging pump (11) Worn impeller	(1) Correct rotation (see Operation 2, (3) ) (2) Contact electric power company and devise counter-measures (3) Check nameplate (4) Recalculate and adjust (5) Recalculate and adjust (6) Raise water level or lower pump (7) Inspect, repair (8) Remove foreign matter (9) Remove foreign matter (10) Disassemble and remove foreign matter (11) Replace impeller
Over current	(1) Unbalanced current and voltage (2) Significant voltage drop (3) Motor phase malfunction (4) Operating 50Hz pump on 60Hz (5) Reverse rotation (6) Low head. Excessive volume of water (7) Foreign matter clogging pump (6) Low head. Excessive volume of water (7) Foreign matter clogging pump (8) Motor bearing is worn or damaged	(1) Contact electric power company and devise counter-measure (2) Contact electric power company and devise counter-measure (3) Inspect connections and magnetic switch (4) Check nameplate (5) Correct rotation (see Operation 2. (3) ) (6) Replace pump with low head pump (5) Disassemble and remove foreign matter (6) Replace pump with low head pump (7) Disassemble and remove foreign matter (8) Replace bearing
Pump vibrates; . excessive operating noise.	(1) Cutoff valve closed too far (2) Piping resonates (3) Reverse rotation	(1) Open cutoff (valve) (2) Improve piping (3) Correct rotation

# Construction

## 1. Sectional view

This drawing represents one of the standard models.  
There may be some variations according to models.



PART NO.	PART NAME
001	CASING
005	INTERMEDIATE CASING
021	IMPELLER
039	KEY
048	IMPELLER NUT
111	MECHANICAL SEAL
115	"O" RING
117-1	GASKET
117-2	GASKET
117-3	GASKET
117-4	GASKET
120-1	BOLT
120-2	BOLT
120-3	BOLT
120-4	BOLT
193	OIL PLUG
219	COMPANION FLANGE
801	ROTOR
802	STATOR
807	BRACKET
811	SUBMERSIBLE CABLE
814	MOTOR FRAME
830	SHAFT
842	MOTOR COVER
848	MOTOR PROTECTOR
849-1	BALL BEARING
849-2	BALL BEARING
852	SWITCH
865	HANDLE

NOTE: SINGLE PHASE MOTOR  
INSTALLED INSIDE  
(852) SWITCH  
(809) CAPACITOR

## 2. Accessories

Companion flange. . . . . 1set

# Disassembly and assembly

## 1. Disassembly

When disassembling pump, provide a piece of cardboard or plywood to place the different parts on as you work. Do not pile parts on top of each other. They should be laid out neatly in rows. As the "O" ring and gasket can not be used again once they are removed, have replacement parts ready.

Disassemble in the following order, referring to the sectional view.

**Be sure to cut off power source before beginning disassembly.**

The procedure for disassembling is given as follows.

- (1) Loosen nuts and remove casing bolts (120-4).  
Raise the motor section and remove pump casing.
- (2) Remove impeller nut (048) and impeller.
- (3) Remove oil plug (193) and drain lubricating oil.
- (4) Remove intermediate casing bolts (120-2) and intermediate casing carefully.  
(Remember that any lubricating oil remaining in the mechanical seal chamber will flow out.)
- (5) Carefully remove mechanical seal, taking care not to scratch sliding surface or motor shaft.

## 2. Assembly

Reassemble in reverse order of disassembly.

Be careful of the following points.

- (1) Replace "O" rings and gaskets.
- (2) Replace every worn or damaged part.
- (3) Check condition of ball bearings, replace, if necessary or if they fail to retain grease.
- (4) Secure the bolts slowly and symmetrically so as to prevent one-sided tightening.
- (5) After completion of assembly, ensure pump can be turned smoothly by hand.

**Note 1:** During re-assembly, rotate the impeller by hand and check for smooth rotation after impeller is replaced (step 2). If rotation is not smooth, perform steps 5) through 3) again.

**Note 2:** Upon completion of re-assembly step 1) rotate the impeller by hand from the suction inlet and check that it rotates smoothly without touching the suction cover before operating the pump.

Distributor: PUMPX  
[www.pumpx.com](http://www.pumpx.com)  
[www.pumpx.vn](http://www.pumpx.vn)

All specifications subject to change without notice.

In this catalog, the particulars in {} are in accordance with the International System of Units (SI) and given for reference only.

## DISTRIBUTED BY



## EBARA CORPORATION

Head Office  
International Division  
OVERSEAS OFFICES  
Manila Office

Bangkok Office  
Jakarta Office  
Beijing Office

11-1, Haneda Asahi-cho, Ota-ku, Tokyo, 144 Japan  
Asahi Bldg, 6-7, Ginza 6-chome, Chuo-ku, Tokyo, 104 Japan

5th Floor, ODC International Plaza 219 Salcedo Street, Legaspi Village Makati, Metro Manila, Philippines  
3 Fl, Acme Bldg, 125 Phetchburi Rd, Rajthevee, Bangkok 10400  
C/O PT Indobara Bahana Jl, Gunung Sahari Raya 57G, Jakarta Indonesia  
605 Beijing Fortune Bldg, 5 Dong Sanhuan Bei-Lu, Chaoyang District Beijing

Phone: Tokyo 3743-6111  
Phone: Tokyo 3289-6111

Phone: 2-816-7524

Phone: 2-216-4935

Phone: 21-4205522

Phone: 1-501-7541

